1

2

FUSIBLE LINK (38) <4N1>
FUSIBLE LINK (36) <4A9, 4B1>

IGNITION SWITCH (IG1)
OR OSS-ECU (IG1)

FUSIBLE LINK (44) <4N1>
FUSIBLE LINK (34) <4A9, 4B1>

8W 8W

RELAY BOX
(ENGINE COMPARTMENT)
(30) 30A

DC/DC CONVERTER

1.25W 2 (C-406)

W 6 (C-417)

9B-R 9B-R

(1)

RELAY BOX (PASSENGER COMPARTMENT) FUSE

1 (C-408)

ETACS-ECU

(9) 15A

3 4 A

INTERIOR LAMP CONTROL CIRCUIT

(5) 10A

CAN DRIVE CIRCUIT

INTERFACE CIRCUIT

13 1 (C-415)

5 6 (C-416)

VANITY MIRROR LAMP (LH, RH)

22 (C-411)

8 (C-417)

4 5 (C-411)

(BR) P

Y (W)

(SB) R <T>P <T>L

<VEHICLES WITHOUT PANORAMA ROOF>

6 2

KEY REMINDER SWITCH (WHEN REMOVING KEY: ON) (C-307)

ON OFF

IGNITION KEY CYLINDER ILLUMINATION LAMP

3 2

FRONT ROOM LAMP (E-09)

OFF DOOR

OFF ON ON OFF

Y (W)

(L) (W)

2 1 1 3

REAR ROOM LAMP (E-04)

DOOR

OFF ON

(B) 2

(E-06) 3

B

19 (C-225)

(GR) 8

UN LOCK LOCK

FRONT DOOR LOCK ACTUATOR (LH) (F-14)

6

B

7 (C-224)

<F>2B

16 14 6

DIAGNOSIS CONNECTOR (C-227)

5 4

B B

9 5

EARTH J/C (C-01)

4 4 4 4

4 1 (C-226) 8

B 9

J/C (4) (C-108)

13

B

11

EARTH J/C (C-01)

B 1

6 8 18 6

<VEHICLES WITHOUT KOS>

C-01 MU801847

C-108 MU801855

C-224

C-225

C-226 MU801586

C-227 FRONT SIDE

C-307 MU801547

C-406 MU801325

C-408

C-411

C-415 MU801890

C-416

C-417

E-04 MU801685

E-06 MU801569

E-09 MU801685

F-14 (MU801845)

Wire colour code
B : Black LG : Light green G : Green L : Blue W : White Y : Yellow SB : Sky blue
BR : Brown O : Orange GR : Grey R : Red P : Pink V : Violet PU : Purple SI : Silver

HBW08E25AC